



wall: white 30x60 11<sup>3/4</sup>"x 23<sup>5/8</sup>" - tipe 20x60 7<sup>7/8</sup>"x 23<sup>5/8</sup>" - decor dark list 2x60 3/4"x 23<sup>5/8</sup>"  
floor: black 60x60 23<sup>5/8</sup>"x 23<sup>5/8</sup>"



wall: white 30x60 11<sup>3/4</sup>"x 23<sup>5/8</sup>" - black 30x60 11<sup>3/4</sup>"x 23<sup>5/8</sup>" - decor white list 2x60 3/4"x 23<sup>5/8</sup>" - decor dark list 2x60 3/4"x 23<sup>5/8</sup>"  
floor: black 60x60 23<sup>5/8</sup>"x 23<sup>5/8</sup>"

## vantaggi / advantages

**1** nessun rumore  
no noise

**2** nessun costo di smaltimento detriti  
no cost for waste disposal

**3** niente polvere  
no dust

**4** è facile da tagliare  
easy to cut

**5** grande rapidità d'esecuzione  
great speed in laying

**6** grande risparmio di denaro  
great saving of mone

## Raccomandazioni per l'impiego e la posa di SLIM/4

### 1 Posa su pavimento preesistente.

SLIM/4 è ideale per rivestire le superfici di vecchi pavimenti in ambienti domestici o commerciali adibiti a traffico leggero.

- Prevedere fughe di almeno 2 mm sul monofornato e necessariamente 3 mm sul multiformato.

- Sottofondo: verificare la planarità delle superfici, livellando se necessario.

- Come collante, utilizzare adesivi per gres porcellanato, scegliendo la tipologia idonea in base alla natura del supporto.

### Modalità di posa.

- Stendere l'adesivo a letto pieno sul pavimento, utilizzando spatole a denti inclinati da 6 mm.

- Applicare il collante sul retro della lastra con una spatola a denti piatti da 3 mm.

- Una volta collocata la lastra, battere accuratamente la superficie con una spatola di gomma per completare l'adesione.

### 2 Posa a rivestimento.

SLIM/4 è utilizzabile per rivestire pareti in abitazioni, edifici o locali pubblici, in interno ed esterno.

E' ideale sia per la posa sovrapposta a vecchi rivestimenti, sia per pareti realizzate ex novo.

- Per il rivestimento prevedere fughe di almeno 1 mm.

- Sottofondo: verificare la planarità delle superfici, livellando se necessario.

- Come collante, utilizzare adesivi per gres porcellanato, scegliendo la tipologia idonea in base alla natura del supporto.

### Modalità di posa.

- Stendere l'adesivo a letto pieno sul supporto, utilizzando una spatola da 4 mm.

- Applicare le lastre da rivestimento.

- Battere bene la superficie con una spatola di gomma, avendo cura di fare aderire completamente le lastre.

### 3 Avvertenze per pavimenti

- SLIM/4 è consigliato soprattutto per l'installazione su pavimenti pre-esistenti. In caso di posa su massetti nuovi, si raccomanda la massima attenzione affinché il sottofondo sia assolutamente compatto, omogeneo e ben livellato e che abbia raggiunto sufficiente stagionatura.

- Rispettare tassativamente tutti i giunti di dilatazione esistenti sul sottofondo e sulle pareti.

- E' utilizzabile in contesti ove non vi sia passaggio di carichi puntuali pesanti, come per esempio il transito di carrelli a ruote dure.

## Prescriptions for the use and installation of SLIM/4

### 1 Laying over an existing floor.

SLIM/4 is the ideal material to cover the surfaces of original floor coverings in the home or in commercial premises subject to light pedestrian traffic.

- Leave joints of at least 2 mm in width when laying a single size and, obligatorily, 3 mm when laying a combination of both sizes.

- Substrate: check that the surfaces are perfectly flat, and level them if necessary.

- Use adhesives for porcelain stoneware, choosing the most suitable type on the basis of the type of substrate.

### Method of installation.

- Spread a continuous film of adhesive on the floor using a 6 mm angled tooth spatula.

- Apply adhesive to the rear of the tile with a 3 mm flat tooth spatula.

- Once the tile has been positioned, tap all over the surface with a rubber spatula to maximise the anchorage.

### 2 Installation on walls.

SLIM/4 can be used as a wall covering in the home and public buildings, both indoors and outdoors.

This material is ideal for installation over existing wall coverings or to create completely new wall coverings.

- For wall coverings leave joints of at least 1 mm in width.

- Substrate: check that the surfaces are perfectly flat, and level them if necessary.

- Use adhesives for porcelain stoneware, choosing the most suitable type on the basis of the type of substrate.

### Method of installation.

- Spread a continuous film of adhesive on the wall using a 4 mm notched spatula.

- Offer the tile up to the wall.

- Tap all over the surface of the tile with a rubber spatula to ensure the slabs are perfectly anchored to the substrate.

### 3 Warnings for floor coverings

- SLIM/4 is primarily recommended for installation on top of existing floor coverings. Before laying it on new floor slabs, please make sure that the substrate has reached the proper weathering.

Pay the utmost attention to ensure that the substrate is perfectly compact, uniform and well levelled.

- We strictly recommend to respect the expansion joints existing on substrate and on both floors and walls. SLIM/4 is suitable for locations that are not subject to high concentrated loads, such as applied by the transit of carts with hard tyres.

# FLORIM

FLORIM CERAMICHE S.p.A.

Via Canaletto, 24 - 41042 Fiorano (MO) - Italy / Tel. +39 0536.840111 - Fax + 390536.840999 / www.florim.it - info@florim.it

# black & white SLIM/4

**F**ORIM

**FLOOR  
GRES**  
MADE IN FLORIM

**rex**  
CERAMICHE ARTISTICHE  
MADE IN FLORIM

**CERIM**  
MADE IN FLORIM

**casamood**  
MADE IN FLORIM

**fin** Casa dolce casa  
MADE IN FLORIM




wall: black 30x60 11<sup>3</sup>/<sub>4</sub>"x 23<sup>5</sup>/<sub>8</sub>" - flower black comp/2 30x60 11<sup>3</sup>/<sub>4</sub>"x 23<sup>5</sup>/<sub>8</sub>"  
floor: black 60x60 23<sup>5</sup>/<sub>8</sub>"x 23<sup>5</sup>/<sub>8</sub>"



wall: black 30x60 11<sup>3</sup>/<sub>4</sub>"x 23<sup>5</sup>/<sub>8</sub>" - box black 30x60 11<sup>3</sup>/<sub>4</sub>"x 23<sup>5</sup>/<sub>8</sub>" - white 30x60 11<sup>3</sup>/<sub>4</sub>"x 23<sup>5</sup>/<sub>8</sub>" - box white 30x60 11<sup>3</sup>/<sub>4</sub>"x 23<sup>5</sup>/<sub>8</sub>"  
floor: black 60x60 23<sup>5</sup>/<sub>8</sub>"x 23<sup>5</sup>/<sub>8</sub>"

# black & white SLIM/4

gres porcellanato smaltato / glazed porcelain stoneware  
Squadrato - Squared



black 60x60 23<sup>5/8</sup>"x 23<sup>5/8</sup>"  
726920  
black lux 60x60 23<sup>5/8</sup>"x 23<sup>5/8</sup>"  
726922



black 30x60 11<sup>3/4</sup>"x 23<sup>5/8</sup>"  
726924  
black lux 30x60 11<sup>3/4</sup>"x 23<sup>5/8</sup>"  
726926



white 60x60 23<sup>5/8</sup>"x 23<sup>5/8</sup>"  
726919  
white lux 60x60 23<sup>5/8</sup>"x 23<sup>5/8</sup>"  
726921



white 30x60 11<sup>3/4</sup>"x 23<sup>5/8</sup>"  
726923  
white lux 30x60 11<sup>3/4</sup>"x 23<sup>5/8</sup>"  
726925



decor dark list 2x60 3/4"x 23<sup>5/8</sup>"  
727367



decor white list 2x60 3/4"x 23<sup>5/8</sup>"  
727366



flower black comp/2 30x60 11<sup>3/4</sup>"x 23<sup>5/8</sup>"  
727379



flower white comp/2 30x60 11<sup>3/4</sup>"x 23<sup>5/8</sup>"  
727378



box black 30x60 11<sup>3/4</sup>"x 23<sup>5/8</sup>"  
727377



box white 30x60 11<sup>3/4</sup>"x 23<sup>5/8</sup>"  
727376



tipe 20x60 7<sup>7/8</sup>"x 23<sup>5/8</sup>" 727375